

Setting the die station numbering

You can number die stations horizontally or vertically, in a snaking or a zigzag pattern.

1. On **job properties** > **Contents**, select the die file.
2. For the **Number order** (under **Attributes**), click **Snaking** or **Zigzag**.
3. In the **Starting point** box, select the location of the first die station in the sequence.
4. In the **Direction** box, select the direction in which you want the snaking or zigzag pattern to progress.
5. In the **Starting #** box, type the starting number you want to use for die station numbering.