

Adding an output device

To produce plates, film, or proofs, set up one or more output devices in the **ShopMap** palette.

1. If the **ShopMap** palette is not currently shown, select **Window > Show ShopMap Palette**.
2. On the **ShopMap** palette, click **Equipment**.
3. Click the **Output Device** tab.
4. Perform one of the following actions:
 - On the **Output Device** tab, select the output device that you want to use, and drag it to the **layout** view.
 - Click the **options** arrow on the **ShopMap** palette and from the menu select **Add to Job**.
 - Click **Add to Job** on the bottom of the **ShopMap** palette.
5. Repeat steps 3–4 for any other output devices required for the job.