

# Editing an existing step-and-repeat layout

You can edit an existing step-and-repeat layout without having to recreate it.

1. In the **layout** view or on the **job properties > Content** tab, press Ctrl + click (right-click) the step-and-repeat. From the menu, select **Edit**.
2. Modify the step-and-repeat parameters.
3. Click **OK**.