

Setting the line appearance in the layout view

You can select which lines will appear in the **layout** view for specific die files.

1. Select **File > Import > Die**.
2. In the Import Die dialog box, browse to the location of the die file, select the file, then click **Import**.
The die appears in the **layout** view.
3. In the **Attributes**, select the **Lines** tab, then select the check box for the line type(s) that you want to show.

A line will show in the **layout** view when its check box is selected.