

Changing work styles

Pandora allows you to create one-sided or two-sided layouts.

For two-sided layouts, select either the sheetwise or the perfector work style. If you select the sheetwise work style, the press prints an image on one side of the substrate, and then uses its gripper and side guides to turn the substrate over so that it can print another image on the other side. If you select the perfector work style, the press prints both sides of the substrate in one pass. You can change work styles while work is in progress. The layout will automatically change for the new style.

1. On the **job properties** pane, select the **Layout** tab.
2. Select the work style you want to use: **Single Sided**, **Sheet Wise**, or **Perfector**.
When a two-sided layout is selected, Pandora identifies the current side shown in the **layout** view as **Front** or **Back**. Use transparency sliders for one or both of the sides to view how the two sides are aligned.